

FITTING SKAMOLEX ANTIQUE BRICK PANELS

These new panels are designed to run the bond of the brickwork when placed on top or alongside each other

BEFORE: A messy brick wall.



Stage 1. Apply half dozen blobs of high temperature silicone to the back of a Skamolex panel.



Stage 2. Place the panel gently in place and secure temporarily.



AND AFTER: a really effective brick effect wall.



Stage 3.
Repeat process with more panels carefully positioning so the joints are lined up. Ensure the panels are held in place until the silicone has cured.

